

- Main objective
  - Removal of heavy metals (Cr) as a posttreatment technology → water reuse
  - Resource recovery (Cr)





→ pH ~neutral and  $Cr^{3+} \& Cr^{6+} (CrO_4^{2-})$ 

→ wastewater discharge limit for Chromium is 100 ppb  $(100 \mu g/L)^2$ .

# **Adsorption** using **Structured sorbents** = key technology to recover/remove **low** concentrations of valuables/undesirable compounds from complex, low-grade matrices



This project has received funding from the European Union's Horizon 2020 research and innovation programme under grant agreement No 821051. This project has been co-funded by Department of Biotechnology (DBT), Government of India.



#### <u>Design of Structured sorbents</u> with <u>specific composition</u> designed (at VITO):

• Granulated composites prepared by intensive mixing technique:



- → pH ~neutral and  $Cr^{3+}$  &  $Cr^{6+}$  ( $CrO_4^{2-}$ )
- $\checkmark$  Cr<sup>6+</sup>  $\rightarrow$  LDH type clay
- ✓  $Cr^{3+}$  → Bentonite Phyllosilicate type clay

		Sorbent 1 (S80/20)	Sorbent 2 (S50/50)	Sorbent 3 (S20/80)
lay	Target Cr species	Cr <sup>3+</sup> /Cr <sup>6+</sup> Mainly Cr <sup>6+</sup>	Cr <sup>3+</sup> /C <sup>r6+</sup> Both in equal proportions	Cr <sup>3+</sup> /Cr <sup>6+</sup> Mainly Cr <sup>3+</sup>



This project has received funding from the European Union's Horizon 2020 research and innovation programme under grant agreement No 821051. This project has been co-funded by Department of Biotechnology (DBT), Government of India.



#### Phase 1: Sorbent composition selection (at VITO)

Composition screening in synthetic Cr solutions



Sorbent1 selected: 80%LDH:20%Bentonite

Desorption optimization and multicycle tests:



• Optimized desorption solution: 2M NaCl at neutral pH



This project has received funding from the European Union's Horizon 2020 research and innovation programme under grant agreement No 821051. This project has been co-funded by Department of Biotechnology (DBT), Government of India.





Phase 2: Testing and Validation (IIT Kanpur)

Ci: 0.5 - 2 mgCr/L in real permeate (IPC membrane filtration)

Dosages Sorbent 1 (g/100mL)	Removal Efficiency
0.5	49-68 %
0.75	66-78 %
1	77-81 %
1.5	76-87 %
2	91-94 %
2.5	93-96 %

- ightarrow At low concentrations, the Cr removal % is dependent of S/L ratio
- ightarrow Complete removal can be achieved with increased S/L ratio
- → Kinetics: pseudo  $2^{nd}$  order → calculation of rate constants

→ Results were used for modelling studies and predict the behaviour under flow conditions

ightarrow which indicated that the

U = Hydraulic loading rate (m<sup>3</sup>/m<sup>2</sup>/h)

is the main parameter affecting the column performances



This project has received funding from the European Union's Horizon 2020 research and innovation programme under grant agreement No 821051. This project has been co-funded by Department of Biotechnology (DBT), Government of India.





Phase 3: Column design & testing at IIT Kanpur

Ci: 1 mgCr/L in real permeate (IPC membrane filtration)





#### Breakthrough curves of Cr(VI) adsorption on structured adsorbent:



\* wastewater discharge limit for Cr is 100 ppb (100µg/L)<sup>1</sup>.



This project has received funding from the European Union's Horizon 2020 research and innovation programme under grant agreement No 821051. This project has been co-funded by Department of Biotechnology (DBT), Government of India.

۲



#### Outcome

- Optimized and validated composition: Structured Sorbent 1: 80%LDH:20% Bentonite
- Multicycle operating process optimized at small scale: Regeneration by 2M NaCl solution & neutral pH
- The small-scale results allowed the design the larger-scale column set-up and experimental testing

#### **Future research perspectives**

- Optimization of operational parameters under flow conditions
- Validation of Multicycle operating process on the larger columns
- Investigation on use/regeneration/disposal of exhausted Structured adsorbents

#### **Opportunity for scale-up**

- Materials: Structured sorbent production commercially available clays (LDH & Bentonite) and granulation technique
- **Application:** Possibility to work with larger columns or multiple columns installations

